

Table 5-1

WDISC COM Port Cabling Pinouts

PTP COM Port - to - 2PK-AB-T1 Switches

Signal	DE9P (DTE)	Signal	DB25S (DCE)
DCD	1	DCD	8
RxD	2	TxD	2
TxD	3	RxD	3
DTR	4	DTR	20
SGND	5	SGND	7
DSR	6	DSR	6
RTS	7	RTS	4
CTS	8	CTS	5
RI	9	RI	22

Note: The CodePAL section must be programmed to Terminal mode.

- Using a terminal emulation program on the PTP, select the COM1, 3, or 4 port (switch 1, 2, 3 respectively). Use 9600 baud, 8-bits, no parity, hardware handshaking.
- Press the ENTER key and a password prompt will appear. The logon password is SN.
- After logon, enter 3 for Programming and verify the following settings:
 1. Device Labels
 2. Password
 3. Baud: 9600
 4. Parity/Data: N,8
 5. Lead: Y
 6. Resp: Y
 7. Mode: Terminal
 8. Cycle Time: 5
 9. Time out: 0
- X Exit
- Enter X to leave Setup and X again to logoff.
- If the Mode was changed from Modem (incorrect setting) to Terminal (correct setting), you must cycle the power on the CodePAL to make it respond to Terminal mode.
- Switch commands are <ESC>SN1A and <ESC>SN1B. Do not use a carriage return!